

To activate layouts on **Bosch AU651** FPK2 (aka gen2) clusters you need:

1. Flash fw version 0095

1. Flash back fw version 0153, 0157, 0211 or 216.
2. In ODIS-E in block 17 login with 20103.
3. Enable up to any 3 adaptations in block 17:

[VN]_designvariant_activation_gen2:

[LN]_variant_1: [VN]_active
[LN]_variant_2: [VN]_not_active
[LN]_variant_3: [VN]_active
[LN]_variant_4: [VN]_active
[LN]_variant_5: [VN]_not_active
[LN]_variant_6: [VN]_not_active
[LN]_variant_7: [VN]_not_active

1. To avoid "Basic settings" error in block 17, enable following adaptation :

[LN]_lock: [VN]_yes

Mapping of variants to layouts:

Variant 1 — Klassik (default)
Variant 2 — S Performance
Variant 3 — Dynamic
Variant 4 — Sport
Variant 5 — RS Performance (this layout not available in fw 0211 but available on 0216)
Variant 6 — RS Sport (this layout not available in fw 0211 but available on 0216)
Variant 7 — RS Runway (this layout is not available in fw 0211+)

Good to know: if you update from 0095 onto 0211 or 0216, you will automatically enable Klassik, Dynamic and Sport layout without need to change any adaptation.