


Connector Diagram:



I. Precautions

- This unit is applied to the following discs:

Logo	Indications	Disc size
	It is applied to MP4 discs saved in the form of .avi, .dat.	12 cm
	It is applied to all functions of DVD VIDEO, DVD-R/ DVD-RW or DVD+R/ DVD+RW under video mode.	12 cm
	It is applied to all functions of video CD or CD-R/ CD-RW under video CD mode.	12 cm
	It is applied to all functions of music CD or CD-R/ CD-RW under music CD mode.	12 cm
MP3	It is applied to all functions of files saved in CD-ROM/ CD-R/ CD-RW/ DVD-R/ DVD-RW/ DVD+R/ DVD+RW in the form of JPEG.	12 cm
JPEG	It is applied to all functions of files saved in CD-ROM/ CD-R/ CD-RW/ DVD-R/ DVD-RW/ DVD+R/ DVD+RW in the form of JPEG.	12 cm

Notes: ● MP4/ DVD/ VCD 1.0/ 1.1/ 2.0/ 3.0 versions, DVD, CD-R/ CD-RM/ MP3/ WMA/ JPEG/ WMV/ MTV/ AVI/ MPG format discs are supported.  
● When playing DVD, VCD, MP3 or CD, the display screen will automatically identify the disc and display corresponding samples. If the screen displays “invalid”, it shows such function is unavailable under this mode, please select another function. Refer to the instructions for specific operation.

- Do not alter the unit yourself to avoid accident.
- Playing disc in bumpy drive or playing non-standard or seriously damaged disc can cause damage to the laser head.
- Clean the laser head with laser head cleaning agent on a regular basis to prevent from dust conglomeration.
- Do not use the unit under a too high or too low temperature. Please make sure that the temperature in car is between -20℃~+60℃ before power-on.
- If the screen displays the icon of while operating, it shows that this operation is not supported or is invalid.
- In case of abnormal phenomenon, please refer to the part of “Troubleshooting” of this manual. You may also press the “RES” button to restore factory defaults.