

MAINTENANCE SCHEDULE - EUROPE 15,000 km/9,000 milesIncludes updates from **MARCH until JUNE '08**

New information: TMC Yaris and Lexus IS Minor Change 08/08; TMMF Yaris Minor Change 08/11; Addition of LS460(L) 4WD (USF45,46); Prius, LC120, LC V8, Lexus GS, LS, SC running change; iQ new model; Avenis Full Model Change

Fill operation added; Fuel Injection system maintenance added (Lexus IS250, GS300 and LS460 for Croatia only)

		MAINTENANCE OPERATIONS														TMC Yaris				TMMF Yaris				TMC Auris		TMUK TMMT Auris							
		I: Inspect and correct or replace as necessary. R: Replace or change or lubricate. F: Fill																															
GASOLINE ENGINE																																	
SERVICE INTERVALS:																																	
Odometer reading or months, whichever comes first		ODOMETER READING										Months (): for reference				1KR-FE (1.0 L3)		2ZR-FE (1.8)		1KR-FE (1.0 L3)		2SZ-FE (1.3)		1NR-FE (1.33)		4ZZ-FE (1.4)		1ZR-FE (1.6)		4ZZ-FE (1.4)		1ZR-FE (1.6)	
		× 1,000 km														KSP90		ZSP90		KSP90		SCP90		NSP90		ZZE150		ZRE151		ZZE150		ZRE151	
MAINTENANCE ITEMS		× 1,000 miles														05/08 08/08(MC) 06/11 0808(MC)		06/01 08/11(MC) 06/01 08/11(MC)		06/01 08/11(MC)		06/10 06/10		07/02 07/02									
Timing Belt		Replace every 150,000 km (90,000 miles)										—																					
Valve Clearance (Sensory Inspection)*1												*I (Every 72 months)				●		●		●				●				●					
Drive belt		V-ribbed belt		Inspect 105,000 km (63,000 miles), after 105,000 km Inspect every 15,000 km (9,000 miles)										Initial: 72 and then every 12 months				●		●		●		●		●		●		●			
Engine oil (API: SH, SJ) (ILSAC)		Normal		R		R		R		R		R		Every 12 months																			
		Severe		R		R		R		R		R		Every 6 months																			
Engine oil (API: SJ, SL) (ILSAC)		Normal		R		R		R		R		R		Every 12 months																			
		Severe		R		R		R		R		R		Every 6 months																			
Engine oil (API: SL, SM) (ILSAC)		Normal		R		R		R		R		R		Every 12 months				●		●		●		●		●		●					
		Severe		R		R		R		R		R		Every 6 months				●		●		●		●		●		●					
Engine oil filter		Normal		R		R		R		R		R		Every 12 months				●		●		●		●		●		●					
		Severe		R		R		R		R		R		Every 6 months				●		●		●		●		●		●					
Cooling and heater system *2				I		I		I		I		Every 24 months				●		●		●		●		●		●		●					
Engine coolant		LLC (red/green) *3						R		R		Initial: 36 months																					
		S-LLC (pink) *4		I		I		I						●		●		●		●		●		●		●		●					
		First replace at 150,000 km (90,000 miles); after, every 90,000 km (54,000 miles)										●		●		●		●		●		●		●		●		●					
Inverter coolant		S-LLC (pink) *4		I		I		I																									
		First replace at 150,000 km (90,000 miles); after, every 90,000 km (54,000 miles)																															
Exhaust pipes and mountings				I		I		I		Every 24 months				●		●		●		●		●		●		●		●					
		Platinum or Iridium Tipped type		Replace every 90,000 km (54,000 miles)										—		●		●		●		●		●		●		●					
Spark plugs		Others		I		R		I		I: Every 24 months R: Every 48 months				●				●		●		●		●		●		●					
Battery		No maintenance										—																					
Fuel filter (Aygo only)		Replace every 180,000 km (108,000 miles)										15 years																					
Fuel injection system		F		F		F		F		F		—																					
Air cleaner filter (from October 2002, applicable to all models in production)		Normal		I		I		R		I		I: Every 24 months R: Every 48 months				●		●		●		●		●		●		●					
		Dusty road		I		I		I		R		I		I: Every 12 months R: Every 48 months				●		●		●		●		●		●					
Air cleaner filter		Normal		I		I		R		I		I: Every 24 months R: Every 48 months																					
		Dusty road		Inspect every 2,500 km(1,500 miles) and replace every 45,000 km(27,000 miles) or 48 months.										—																			
Fuel tank cap, fuel lines, connections and fuel vapor control valve				I		I		I		Every 24 months				●		●		●		●		●		●		●		●					
Charcoal canister		*5						I		—				●		●		●		●		●		●		●		●					
		Others				I		I		Every 24 months				●		●		●		●		●		●		●		●					
		Aygo only		Normal		I		I		—																							
		Severe				I		I		Every 24 months																							
Charcoal canister filter		Aygo only		Normal		R		R		—																							
		Severe				R		R		Every 24 months																							