



Terminal Identification



Revised: 7/9/2010

230-58000

Replacement for:

KOKUSAN-DENKI
RS5121

Repair Lead Part Number
500-22012



NOTE:

* TERMINAL IS **NOT** AN INDICATOR LIGHT. IT IS A TERMINAL THAT BECOMES POSITIVE (+) WHEN ALTERNATOR IS CHARGING.

★ TERMINAL BECOMES NEGATIVE (-) WHEN ALTERNATOR IS CHARGING.



CAUTION: Only trained professionals who have the proper tools, equipment and training to perform the procedures contained herein should use this information. All others should refer work to a qualified technician. Disconnect this item from all sources of power prior to performing work. Use proper safety equipment and procedures at all times. J&N accepts no liability, express or implied, for any injuries or damages incurred while attempting these procedures.

www.jnelectric.com • 800-366-7100

10995 Canal Rd., Cincinnati, OH 45241-1886

© 2010, J&N Auto Electric, Inc. All rights reserved. Trademarks used herein are the property of their respective owners.