

- ☐ **Service A**
- ☐ **Service B**
- ☐ Plus package
- ☐ For every service (equipment specific)
- ☐ Once at 3,000 km (1,850 mi)
- ☐ Service 3 At every service
- ☐ Service 4 Every 2 years
- ☐ Service 8 Every 50,000 km (31,000 mi) / 3 years
- ☐ Service 8 Every 75,000 km (46,500 miles) / 4 years
- ☐ Service 11 every 200,000 km (125,000 miles)/10 years
- ☐ Service 12 Every 75,000 km (46,500 miles) / 4 years
- ☐ Service 13 every 200,000 km (125,000 miles)/10 years
- ☐ Service 14 every 50,000 km (31,000 miles) / 3 years
- ☐ Service 20 Once at 50,000 km (31,000 mi) / 3 years
- ☐ Service 20 Every 125,000 km (77,500 miles) /5 years
- ☐ Service 20 every 125,000 km (77,500 mi)



Page 1 of 5

		<p>i To be performed by the Service Advisor (where market-specific conditions require). The service scope is only completely performed when all acceptance items and the maintenance items listed in the service sheet have been fully processed.</p>	
<input type="checkbox"/>	<input type="checkbox"/>	Brake system Perform brake test and enter the result in the table ○	AP42.00-P-4290BA
	<input type="checkbox"/>	Vehicle exterior Check exterior lights for proper operation ○	AP82.10-P-8252EW
	<input type="checkbox"/>	Check operation of headlamp range adjustment ○ Vehicles with Xenon headlamps or dynamic LED headlamps or headlamp range controller on the exterior lights switch	AP82.10-P-8250EW
	<input type="checkbox"/>	Check/correct headlamp adjustment ○ <i>i</i> On vehicles equipped with Xenon or dynamic LED headlamps, adjustment of the headlamps is to be invoiced as an additional operation.	AP82.10-P-8260R
	<input type="checkbox"/>	Vehicle interior Check windshield wipers, windshield washer system and headlamp cleaning system for proper operation ○	AP82.30-P-8252RK
<input type="checkbox"/>	<input type="checkbox"/>	Replace activated charcoal dust filter	AP83.00-P-8384CW
<input type="checkbox"/>	<input type="checkbox"/>	Engine compartment Clean water drain	AP82.35-P-8232A
<input type="checkbox"/>	<input type="checkbox"/>	Brake system: Check fluid level ○	AP42.10-P-4210V
	<input type="checkbox"/>	Active Body Control (ABC): Check fluid level ○ With code 487 (Active Body Control (ABC))	AP32.50-P-3213SX
	<input type="checkbox"/>	Check low-temperature circuit coolant level ○ Engine 157, 278 Engine 276.8 Engine 279	AP20.30-P-2052G AP20.30-P-2052H AP20.30-P-2052I
	<input type="checkbox"/>	Check all visible parts in engine compartment for damage and leaks ○	AP00.20-P-0055EW
	<input type="checkbox"/>	Check visible area of poly-V belt for wear ○	AP13.22-P-1352EW
	<input type="checkbox"/>	Underside of vehicle Check all visible parts of vehicle underside for damage and leaks ○	AP00.20-P-0054EW
	<input type="checkbox"/>	<i>i</i> The country-specific regulations for mobility and body shell complaints apply. Check track rod and drag link linkage for play, check boots ○	AP46.00-P-4653EW
	<input type="checkbox"/>	Check front axle ball joint for play, check boots ○	AP33.20-P-3353SX
	<input type="checkbox"/>	Check condition of propeller shaft and flex disks ○	AP41.10-P-4152EW

	<input type="checkbox"/>	Check tires for damage and crack formation and enter result in table	○	AP40.10-P-4051EW
<input type="checkbox"/>	<input type="checkbox"/>	Tires Plus package Correct tire pressure and enter set tire pressure in table	○	AP40.15-P-4061A
<input type="checkbox"/>	<input type="checkbox"/>	Trunk Plus package Check/correct spare wheel tire pressure and enter set tire pressure in table	○	AP40.15-P-4061A
<input type="checkbox"/>	<input type="checkbox"/>	Vehicles with spare tire		
<input type="checkbox"/>	<input type="checkbox"/>	Check TIREFIT tire sealant	○	AP40.10-P-4054R
		Vehicles fitted with TIREFIT		
		Enter TIREFIT expiration date here:		
		Replace TIREFIT, invoice as additional operation.		
<input type="checkbox"/>	<input type="checkbox"/>	Check first aid bag	○	AP68.00-P-6850EW
		Enter first aid bag expiration date here:		
		Replace first aid bag, invoice as an additional operation.		
<input type="checkbox"/>	<input type="checkbox"/>	Check trunk illumination for proper operation	○	
<input type="checkbox"/>	<input type="checkbox"/>	Engine compartment Plus package Windshield washer system: Check/correct fluid level		AP82.35-P-8210EW
		Use summer/winter cleaner as well as its mixing ratio to match the ambient temperature.		
<input type="checkbox"/>	<input type="checkbox"/>	Vehicle interior Plus package Check lamps in the instrument cluster and interior illumination for proper operation	○	AP54.30-P-5453RK
<input type="checkbox"/>	<input type="checkbox"/>	Vehicle interior For every service (equipment specific) Replace battery for KEYLESS-GO key		
		After consultation with customer With code 889 (KEYLESS-GO)		
<input type="checkbox"/>	<input type="checkbox"/>	Underside of vehicle Once at 3,000 km (1,850 mi) Rear axle: Perform oil change		AP35.00-P-3501CMG
		With code 471 (Manual locking differential)		
<input type="checkbox"/>	<input type="checkbox"/>	Engine compartment Service 3 At every service Engine: Change oil and filter		AP18.00-P-0101EWG
		Engine 157		AP18.00-P-0101CWZ
		Engine 276		AP18.00-P-0101EW
		Engine 278		AP18.00-P-0101BA
		Engine 279		
<input type="checkbox"/>	<input type="checkbox"/>	Engine compartment Service 4 Every 2 years Brake system: Replace brake fluid		AP42.00-P-4280V

<input type="checkbox"/>	<input type="checkbox"/>	Engine compartment Service 8 Every 50,000 km (31,000 mi) / 3 years Replace air filter element Engine 157 Engine 279	AP09.10-P-0980AB AP09.10-P-0980SZ
<input type="checkbox"/>	<input type="checkbox"/>	Underside of vehicle Service 8 Every 50,000 km (31,000 mi) / 3 years Rear axle: Perform oil change With code 471 (Manual locking differential)	AP35.00-P-3501CMG
<input type="checkbox"/>	<input type="checkbox"/>	Engine compartment Service 8 Every 75,000 km (46,500 miles) / 4 years Replace air filter element Engine 276.8 Engine 276.9 Engine 278	AP09.10-P-0980E AP09.10-P-0980MM AP09.10-P-0980AB
<input type="checkbox"/>	<input type="checkbox"/>	Trunk Service 11 every 200,000 km (125,000 miles)/10 years Replace fuel filter	AP47.20-P-0780RK
<input type="checkbox"/>	<input type="checkbox"/>	Engine compartment Service 12 Every 75,000 km (46,500 miles) / 4 years Replace spark plugs Engine 157, 276, 278 Engine 279	AP15.10-P-1580V AP15.10-P-1580AAA
<input type="checkbox"/>	<input type="checkbox"/>	Underside of vehicle Service 13 every 200,000 km (125,000 miles)/10 years Replace main circuit coolant Engine 157, 276, 278	AP20.00-P-2080V
<input type="checkbox"/>	<input type="checkbox"/>	Replace low-temperature circuit coolant Engine 157, 276.8, 278 Engine 279	AR20.00-P-1142RK AP20.00-P-2083A
<input type="checkbox"/>	<input type="checkbox"/>	Underside of vehicle Service 14 every 50,000 km (31,000 miles) / 3 years Replace main circuit coolant Engine 279	AP20.00-P-2080AC
<input type="checkbox"/>	<input type="checkbox"/>	Underside of vehicle Service 20 Once at 50,000 km (31,000 mi) / 3 years Automatic transmission: Carry out oil and filter change Transmission 722.931	AP27.00-P-2702W
<input type="checkbox"/>	<input type="checkbox"/>	Underside of vehicle Service 20 Every 125,000 km (77,500 miles) / 5 years Automatic transmission: Carry out oil and filter change Transmission 722.9 except 722.931 up to code 805 (model year 2015) Transmission 725.0 up to code 805 (model year 2015)	AP27.00-P-2702W AP27.00-P-2702B
<input type="checkbox"/>	<input type="checkbox"/>	Underside of vehicle Service 20 every 125,000 km (77,500 mi) Automatic transmission: Carry out oil and filter change Transmission 722.9 except 722.931 as from code 806 (Model year 2016) Transmission 725.0 as from code 806 (model year 2016)	AP27.00-P-2702W AP27.00-P-2702B

Brake values

	Left	Right
Front		
Rear		
Parking brake		

Tire condition

	Right front	Left front	Right rear	Left rear
Condition OK.				
Condition not OK.				

Set tire pressure in bar or psi

	Front axle	Rear axle	Spare wheel
bar/psi			