


Dynaudio Amplifier 3C0 035 456

harness connector A, 24-pin (grey)

- 01 = 🔊 Treble speaker rear left, plus
- 02 = 🔊 **Bass** speaker rear right, minus
- 03 = 🔊 **Bass** speaker rear right, plus
- 04 = 🔊 **Bass** speaker rear left, plus
- 05 = 🔊 Treble speaker rear right, minus
- 06 = 🔊 Treble speaker rear right, plus
- 07 = 🔊 Treble speaker rear left, minus
- 08 = 🔊 **Bass** speaker front left, minus
- 09 = 🔊 **Bass** speaker front left, plus
- 10 = 🔊 **Bass** speaker rear left, minus
- 11 = 🔊 Midrange speaker front right, minus
- 12 = 🔊 Midrange speaker front right, plus
- 13 = unused
- 14 = 🔊 Audio signal in, rear left, minus
- 15 = 🔊 Audio signal in, rear left, plus
- 16 = unused
- 17 = 🔊 Audio signal in, rear right, minus
- 18 = 🔊 Audio signal in, rear right, plus
- 19 = Control in (optional)
- 20 = 🔊 Audio signal in, front left, minus
- 21 = 🔊 Audio signal in, front left, plus
- 22 = unused
- 23 = 🔊 Audio signal in, front right, minus
- 24 = 🔊 Audio signal in, front right, plus



harness connector B, 23-pin (green)

- 01 = 📶 CAN, low
- 02 = 🔊 Midrange speaker front left, minus
- 03 = 🔊 Midrange speaker front left, plus
- 04 = 📶 CAN, high
- 05 = unused
- 06 = 🔊 Treble speaker front left, minus
- 07 = unused
- 08 = unused
- 09 = 🔊 Treble speaker front left, plus
- 10 = unused
- 11 = 🔊 **Bass** speaker front right, plus
- 12 = 🔊 **Bass** speaker front right, minus
- 13 = unused
- 14 = unused
- 15 = 🔊 Treble speaker front right, plus
- 16 = ⚡ Voltage, Ground
- 17 = unused
- 18 = 🔊 Treble speaker front right, minus
- 19 = ⚡ Voltage, Ground
- 20 = ⚡ Voltage, plus 12V
- 21 = ⚡ Voltage, plus 12V
- 22 = ⚡ Voltage, Ground
- 23 = ⚡ Voltage, plus 12V

